

Transponder mounting location

MODIFIEDS: Transponders are required, and are to be attached to the torque plate (back of engine block) on the right side of the car 72" from centerline of rear axle

SPORTSMAN AND HOBBY STOCK: Transponder must be located so that the transponders center line is 165 inches from the furthest forward edge of nose.

HORNETS: Transponder must be located so that the transponders center line is 150 inches from the furthest forward edge of nose.

6 SHOOTERS: Transponders are mandatory and located approximately 20" (inches) in from rear bumper outside the car mounted on the spare tire hump under the car facing downward with a clear view to the track surface.

LEGENDS: Transponder must be located on the right hand side below the panhard bar mount.

BANDOLEROS: Transponder must be located in front of the left front tire mounted parallel to the chassis